Inventory Available		
110 Film	Stock Number	Special Notes
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II		
Carlott CarloScart 6400/0000/0000/0900/9000/9930 and Wark II	110-C	
- V=0/=0/000/000		
Epson V700/750/800/850	110-E	800 & 850 use requires film area guide
Epson Perfection 4990	110-4990	Requires Film Area Guide
Epson Perfection V550/V600	110-550	
Epson Perfection 3170	110-3170	
Epson Perfection 4180	110-4180	
Epson Perfection V100/200/300/330/370 film scanners	110-100	
Epson Stylus RX500/RX600 scanners	110-RX500	
Francisco Odfo Oceano	110.0150	
Epson Perfection 2450 Scanner	110-2450	
Epson Perfection 4870 Scanner	110-4870	
Epson Perfection V500 and 4490 Film Scanners	110-500	0 N - (- 11011
Jumbl 22MP & ION PIC2SD Scanners	110-ION	See Note "C"
Plustek Opticfilm film scanners	110-Plustek	See Note "B" for supported models
Reflecta 7200/ProScan 10T/Pacific Image PrimeFilm 7200U	110-Reflecta	Does not require cutting strips
Vupoint film and slide converters/scanners	110-Vupoint	Does not require cutting strips
Nikon Coolscan Scanners	110-Nikon	See Note "A" at bottom
Epson V700/750/800/850 (Cross way holder)	110-E-Cross	Does not require cutting strips
Canon CanoScan 8400 (Cross way holder)	110-C-Cross	Does not require cutting strips
Epson V700/750/800/850 - 2 Strip	110-2-E	\$21.00
Epson V500/V550/V600 - 2 Strip	110-2-550	\$21.00
126 Film	Stock Number	Special Notes
1201 1111	Otock Number	Operati Notes
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II		
Carlott Garlogodit G-00/0000/0000/0000/0000/0000/0000/	126-C	
Epson V700/750/800/850	126-E	800 & 850 use requires film area guide
Epson Perfection 4990	126-4990	Requires Film Area Guide
Epson Perfection V550/V600	126-550	1.toquiloo i iiii 7.toq odido
Epson Perfection 3170	126-3170	
Epson Perfection 4180	126-4180	
Epson Perfection V100/200/300/330/370 film scanners	126-100	
Epson Stylus RX500/RX600 scanners	126-RX500	
Epoon Otylas (17.000/17.000 Soaimois	120 11/1000	

Epson Perfection 2450 Scanner	126-2450	
Epson Perfection 4870 Scanner	126-4870	
Epson Perfection V500 and 4490 Film Scanners	126-500	
Jumbl 22MP & ION PIC2SD Scanners	126-ION	See Note "C"
Plustek Opticfilm film scanners	126-Plustek	See Note "B" for supported models
Reflecta 7200/ProScan 10T/Pacific Image PrimeFilm 7200U	126-Reflecta	Does not require cutting strips
Vupoint film and slide converters/scanners	126-Vupoint	Does not require cutting strips
APS Film	Stock Number	Special Notes
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II		
	APS-C	
Epson V700/750/800/850	APS-E	800 & 850 use requires film area guide
Epson Perfection 4990	APS-4990	Requires Film Area Guide
Epson Perfection V550/V600	APS-550	
Epson Perfection 3170	APS-3170	
Epson Perfection 4180	APS-4180	
Epson Perfection V100/200/300/330/370 film scanners	APS-100	
Epson Stylus RX500/RX600 scanners	APS-RX500	
Epson Perfection 2450 Scanner	APS-2450	
Epson Perfection 4870 Scanner	APS-4870	
Epson Perfection V500 and 4490 Film Scanners	APS-500	
Jumbl 22MP & ION PIC2SD Scanners	APS-ION	See Note "C"
Plustek Opticfilm film scanners	APS-Plustek	See Note "B" for supported models
Reflecta 7200/ProScan 10T/Pacific Image PrimeFilm 7200U	APS-Reflecta	Does not require cutting strips
Vupoint film and slide converters/scanners	APS-Vupoint	Does not require cutting strips
Nikon Coolscan Scanners	APS-Nikon	See Note "A" at bottom
Epson V700/750/800/850 (Cross way holder)	APS-E-Cross	Does not require cutting strips
Canon CanoScan 8400 (Cross way holder)	APS-C-Cross	Does not require cutting strips
127 Film	Stock Number	Special Notes
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II		
	127-C	
Epson V700/750/800/850	127-E	800 & 850 use requires film area guide
Epson Perfection 4990	127-4990	Requires Film Area Guide
Epson Perfection V550/V600	127-550	
Epson Perfection 3170	127-3170	
Epson Perfection 4180	127-4180	

Epson Perfection V100/200/300/330/370 film scanners	127-100	
Epson Stylus RX500/RX600 scanners	127-RX500	
Epson Perfection 2450 Scanner	127-2450	
Epson Perfection 4870 Scanner	127-4870	
Epson Perfection V500 and 4490 Film Scanners	127-500	
35 mm Film (full width) - Allows scanning of sprockets	Stock Number	Special Notes
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II		
	35-C	
Epson V700/750/800/850	35-E	800 & 850 use requires film area guide
Epson Perfection V550/V600	35-550	
Epson Perfection 3170	35-3170	
Epson Perfection 4180	35-4180	
Epson Perfection V100/200/300/330/370 film scanners	35-100	
Epson Stylus RX500/RX600 scanners	35-RX500	
Epson Perfection 2450 Scanner	35-2450	
Epson Perfection 4870 Scanner	35-4870	
Epson Perfection V500 and 4490 Film Scanners	35-500	
8 mm movie film (Regular or Super 8)	Stock Number	Special Notes
	Stock Number	Special Notes
8 mm movie film (Regular or Super 8) Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II		Special Notes
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II	8-C	
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II Epson V700/750/800/850	8-C 8-E	800 & 850 use requires film area guide
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II Epson V700/750/800/850 Epson Perfection 4990	8-C 8-E 8-4990	
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II Epson V700/750/800/850 Epson Perfection 4990 Epson Perfection V550/V600	8-C 8-E 8-4990 8-550	800 & 850 use requires film area guide
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II Epson V700/750/800/850 Epson Perfection 4990 Epson Perfection V550/V600 Epson Perfection 3170	8-C 8-E 8-4990 8-550 8-3170	800 & 850 use requires film area guide
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II Epson V700/750/800/850 Epson Perfection 4990 Epson Perfection V550/V600 Epson Perfection 3170 Epson Perfection 4180	8-C 8-E 8-4990 8-550 8-3170 8-4180	800 & 850 use requires film area guide
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II Epson V700/750/800/850 Epson Perfection 4990 Epson Perfection V550/V600 Epson Perfection 3170 Epson Perfection 4180 Epson Perfection V100/200/300/330/370 film scanners	8-C 8-E 8-4990 8-550 8-3170 8-4180 8-100	800 & 850 use requires film area guide
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II Epson V700/750/800/850 Epson Perfection 4990 Epson Perfection V550/V600 Epson Perfection 3170 Epson Perfection 4180 Epson Perfection V100/200/300/330/370 film scanners Epson Stylus RX500/RX600 scanners	8-C 8-E 8-4990 8-550 8-3170 8-4180 8-100 8-RX500	800 & 850 use requires film area guide
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II Epson V700/750/800/850 Epson Perfection 4990 Epson Perfection V550/V600 Epson Perfection 3170 Epson Perfection 4180 Epson Perfection V100/200/300/330/370 film scanners Epson Stylus RX500/RX600 scanners Epson Perfection 2450 Scanner	8-C 8-E 8-4990 8-550 8-3170 8-4180 8-100 8-RX500 8-2450	800 & 850 use requires film area guide
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II Epson V700/750/800/850 Epson Perfection 4990 Epson Perfection V550/V600 Epson Perfection 3170 Epson Perfection 4180 Epson Perfection V100/200/300/330/370 film scanners Epson Stylus RX500/RX600 scanners Epson Perfection 2450 Scanner Epson Perfection 4870 Scanner	8-C 8-E 8-4990 8-550 8-3170 8-4180 8-100 8-RX500 8-2450 8-4870	800 & 850 use requires film area guide
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II Epson V700/750/800/850 Epson Perfection 4990 Epson Perfection V550/V600 Epson Perfection 3170 Epson Perfection 4180 Epson Perfection V100/200/300/330/370 film scanners Epson Stylus RX500/RX600 scanners Epson Perfection 2450 Scanner Epson Perfection 4870 Scanner Epson Perfection V500 and 4490 Film Scanners	8-C 8-E 8-4990 8-550 8-3170 8-4180 8-100 8-RX500 8-2450 8-4870 8-500	800 & 850 use requires film area guide Requires Film Area Guide
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II Epson V700/750/800/850 Epson Perfection 4990 Epson Perfection V550/V600 Epson Perfection 3170 Epson Perfection 4180 Epson Perfection V100/200/300/330/370 film scanners Epson Stylus RX500/RX600 scanners Epson Perfection 2450 Scanner Epson Perfection 4870 Scanner Epson Perfection V500 and 4490 Film Scanners Jumbl 22MP & ION PIC2SD Scanners	8-C 8-E 8-4990 8-550 8-3170 8-4180 8-100 8-RX500 8-2450 8-2450 8-4870 8-500 8-ION	800 & 850 use requires film area guide Requires Film Area Guide See Note "C"
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II Epson V700/750/800/850 Epson Perfection 4990 Epson Perfection V550/V600 Epson Perfection 3170 Epson Perfection 4180 Epson Perfection V100/200/300/330/370 film scanners Epson Stylus RX500/RX600 scanners Epson Perfection 2450 Scanner Epson Perfection 4870 Scanner Epson Perfection V500 and 4490 Film Scanners Jumbl 22MP & ION PIC2SD Scanners Plustek Opticfilm film scanners	8-C 8-E 8-4990 8-550 8-3170 8-4180 8-100 8-RX500 8-2450 8-2450 8-4870 8-500 8-ION 8-Plustek	800 & 850 use requires film area guide Requires Film Area Guide See Note "C" See Note "B" for supported models
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II Epson V700/750/800/850 Epson Perfection 4990 Epson Perfection V550/V600 Epson Perfection 3170 Epson Perfection 4180 Epson Perfection V100/200/300/330/370 film scanners Epson Stylus RX500/RX600 scanners Epson Perfection 2450 Scanner Epson Perfection 4870 Scanner Epson Perfection V500 and 4490 Film Scanners Jumbl 22MP & ION PIC2SD Scanners Plustek Opticfilm film scanners Reflecta 7200/ProScan 10T/Pacific Image PrimeFilm 7200U	8-C 8-E 8-4990 8-550 8-3170 8-4180 8-100 8-RX500 8-2450 8-4870 8-500 8-ION 8-Plustek 8-Reflecta	800 & 850 use requires film area guide Requires Film Area Guide See Note "C" See Note "B" for supported models Does not require cutting strips
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II Epson V700/750/800/850 Epson Perfection 4990 Epson Perfection V550/V600 Epson Perfection 3170 Epson Perfection 4180 Epson Perfection V100/200/300/330/370 film scanners Epson Stylus RX500/RX600 scanners Epson Perfection 2450 Scanner Epson Perfection 4870 Scanner Epson Perfection V500 and 4490 Film Scanners Jumbl 22MP & ION PIC2SD Scanners Plustek Opticfilm film scanners	8-C 8-E 8-4990 8-550 8-3170 8-4180 8-100 8-RX500 8-2450 8-2450 8-4870 8-500 8-ION 8-Plustek	800 & 850 use requires film area guide Requires Film Area Guide See Note "C" See Note "B" for supported models

Epson V700/750/800/850 (Cross way holder)	8-E-Cross	Does not require cutting strips
Canon CanoScan 8400 (Cross way holder)	8-C-Cross	Does not require cutting strips
828 Film	Stock Number	Special Notes
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II		
Fnoon \/700/750/000/050	828-C	000 9 050
Epson V700/750/800/850 Epson Perfection 4990	828-E 828-4990	800 & 850 use requires film area guide
Epson Perfection V550/V600	828-4990	Requires Film Area Guide
Epson Fenection v350/v600	020-000	
616 Film	Stock Number	Special Notes
	Otook (Vallibe)	opeoidi (Votes
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II		
	616-C	
Epson V700/750/800/850	616-E	
Epson Perfection V550/V600	616-550	
Kodak Disc	Stock Number	Special Notes
*with noted exceptions, you MUST remove center hub from Disc!		
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II		
	Disc-C	
Epson V700/750/800/850	Disc-E	Does not require removal of hub
Epson V700/750/800/850 - 3 Disc Holder	Disc-E-3	Does not require removal of hub - \$21.00
Epson Perfection V550/V600	Disc-550	
Epson Perfection V500 and 4490 Film Scanners	Disc-500	
Minox	Stock Number	Special Notes
IVIII IOX	Stock Number	Special Notes
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II		
Canoni Canocican o 100/0000/0000/0000/0000 and mankin	Minox-C	
Epson V700/750/800/850	Minox-E	800 & 850 use requires film area guide
Epson Perfection V550/V600	Minox-550	
Epson Perfection V100/200/300/330/370 film scanners	Minox-100	
Epson Stylus RX500/RX600 scanners	Minox-RX500	
Epson Perfection V500 and 4490 Film Scanners	Minox-500	
Realist 3D Mounted Slides	Stock Number	Special Notes
Comes with two trays except V500 model has one tray		

Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II		
	Realist-C	
Epson V700/750/800/850	Realist-E	800 & 850 use requires film area guide
Epson Perfection V550/V600	Realist-550	
Epson Perfection V500 and 4490 Film Scanners	Realist-500	
Bowers/Polaroid/Nikon ES-1 35 mm film adapters		
35 mm film holder/adapter made for Polaroid/Bowers HD Slide Duplic	atd P-35	
Nikon ES-1	Nikon-ES	
35 mm film holder made for Opteka Slide Duplicator	Opteka-35	
35 mm for Nikon Coolscan - FH-3 Replacement	Nikon-35	See Note "A" at bottom
126 Mounted Slides (50 mm mounts only)		
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II		
	126-Slide-C	
Epson V700/750/800/850	126-Slide-E	800 & 850 use requires film area guide
Epson Perfection V550/V600	126-Slide-550	
110 Mounted Slides (50 mm mounts only)		
Canon CanoScan 8400/8600/8800/8900/9000/9950 and Mark II		
	110-Slide-C	
Epson V700/750/800/850	110-Slide-E	800 & 850 use requires film area guide
Epson Perfection V550/V600	110-Slide-550	
122 Film		
Epson Perfection V700/V750/800/850	122-E	

Notes:

A: This holder requires use of the MA-20 or MA-21 slide mount adapter. Works with the following Coolscan models: LS-40, LS-50, LS-4000, LS-5000, V ED. These are a unique holder and they don't work like most of my other film holders. Please visit http://www.negative-solutions.com/assets/coolscan2.pdf to read up on how they work before ordering.

B: Plustek Opticfilm models: 7200, 7200i, 7200i SE, 7300, 7400, 7500i, 7500i SE, 7500i AI, 7600i SE, 7600i AI, 8100, 8200i SE, and 8200i AI. Strips do not need to be cut.

C: Only works with ION PICS2SD, not ION Film 2 SD Plus. I do have one that will work for the latter. Contact for more info. Users have reported that when using this holder on 126 film, some minor cropping will occur at the bottom and top of your image as the CCD sensor is not wide enough to capture the entire dimensions of 126 film.